D3 Sound Shield


INSTALLATION INSTRUCTIONS

The D3 Sound Shield is intended for professional use only and should be handled and installed by authorized installers.

- Do not connect the unit to other supplies than 12 (12-16) V DC.
- It will not work properly before the unit has been charged for 6 hours.
- The battery must be changed every third year.
- While dealing with the PCB's inside the unit, precautions must be observed for handling electrostatic discharge sensitive devices.
- · It's recommended to use earplugs when installing

Tools needed:


- Screwdriver
- · Torx wrench
- · Screws and drill for mounting the unit




Texecom makes no representation that this product will prevent personal injury or property loss or that the product will in all cases provide adequate warning or protection. Purchaser should understand that a properly installed and maintained alarm system may only reduce the risk of a burglary, robbery or fire without warning, but the alarm is not insurance or a guarantee that such will not occur or that there will be no personal injury or property loss as a result. THEREFORE, TEXECOM SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES IN CONNECTION WITH THE USE, INSTALLATION AND/OR MAINTENANCE OF THE PRODUCT. Including, but not limited to the liability for any property demage, bodily injury, or other loss based on a claim that the product failed to give warning, or any cost of expense of providing substitute equipment or service during periods of malfunction, nonuse or maintenence. In no event shall the liability of Indusec exceed the purchase price of the product.

Texecom

1. THE UNIT











Option: Multiple units

Multiple units can be attached together forming either a semi circle or a full circle. The Semi-circle unit can be mounted either on the wall or the ceiling while the Omni version works best hanging from the ceiling.





GND = Ground
TRG OUT = Bad battery signal, see below
TRG + = Positive activation
TRG - = Negative activation
12 V IN = Charge +12 V DC
9.6 V OUT = Reserve
SAB OUT = Tamper out
SAB IN = Tamper in

Bad battery signal

- Dip switch: 8 ON
- Connector: pin 7 and 8 (TRG OUT and GND)

1. Charging Indication

ON = A red light will lit when charging.

OFF = No indication when charging. (default)

2. Delay between received trigger signal and the alarm sounding.

ON = 30 s

OFF = 0 s (default)

3. Test Mode

ON = Test mode, four short different-pitched sound signals.

OFF = Normal mode (default)

4. Alarm Signal Length

ON = Infinite alarm

OFF = 3 min, after a new trig is needed (default)

5. Reserve

6. Fixed Alarm Signal Length

ON = 45 s

OFF = Normal mode (default)

7. Sound level


ON = $127 \pm 1 \, dB(A) \, @ \, 1m$. 20 s and then $124 \pm 1 \, dB(A) \, @ \, 1m$

1m. NOTE! Very high sound level. OFF = 125 ± 1 dB(A) @ 1m (default)

8. Automatic Battery Check

ON = Bad battery signal on pin 7 on Connector, see below

OFF = Led flash => Bad battery (default)





Option: Tamper

The tamper loop is an extra mechanical security protection. It is not needed for the function of the siren.

The tamper loop consists of a series connection that enters at the Connector at SAB IN goes through the microswitch at the end of the board, runs through the CPU board through the middle connector to the speaker board through the microswitchon that very end and back to the Connector at SAB OUT.

The loop can contain other normally-closed switches such as magnetic contacts or mercury tilt switches in the alarm setup.

4. ASSEMBLING THE UNIT

- 1. Before applying power to the unit, ensure that Dip switch 3 is in the ON position = Test
- 2. Assemble the two PCB's and the battery. Attach the battery cable to the connector.
- 3. Power can now be applied.
- 4. Set Dip switch 1 to ON. A red LED on the CPU circuit board should light up.
- 5. Dip switch 1 can be in either in ON or OFF mode.
- 6. Set the Dip switch 3 to OFF = Normal mode. Attach the grid and the two end caps.
- 7. The D3 Sound Shield is assembled and ready for use.

5. TEST

We recommend testing the unit either before mounting or during assembling.

Without a connected Tamper loop it is only necessary to connect the two PCB's, the battery and power.

Test procedure (The battery will need about 20 minutes to charge before testing.);

- 1. Set Dip switch 3 to ON position.
- 2. Activate either Trigger signal.
- 3. The unit should generate four short different-pitched sound signals indicating that the unit works.
- 4. Switch off the Trigger signal.
- 5. Set Dip switch 3 to OFF position. (Normal operation mode)
- 6. The test is complete.

6. SPECIFICATIONS

Coverage Up to 150 cubic meters (60 square meters x 2.5)

Electrical interface

Power Supply 12 – 16 V DC, < 150 mA

Activation Signals Trig (-): 0 - 0.5 V, (10 mA) Trig (+): 9 - 18 V, (10 mA)

Cables 0.25 – 1.0 square mm, (AWG 22 – 18)

Battery 9.6 V Ni-MH, NI-MH batteries performance is improved if charged discharged.

Capacity 1800 mAh. (sufficient for 30 minutes continuous alarm)

Charge time The unit should be charged 6 hours before use.

Standby w/o battery charge 1 month

Life time 3 years, then it has to be replaced

Sound output $125-127 \pm 1 \, dB(A)$ @ 1m, user selectable

Output frequency 2-5 kHz